







## 1730

- Piletta per cerniera. Quadro italiano.
- Punto de giro inferior con cuadro italiano.
- Bottom pin for hinges with Italian pivot housing.
- Unterer Zapfen für Band. Italienscher Gehäuse.
- Axe de pivot Italien.






## 1732

- Piletta per cerniera. Quadro spagnolo.
- Punto de giro inferior cuadro Español.
- Bottom pin for hinges with Spanish pivot housing.
- Unterer Zapfen für Band. Spanischer Gehäuse.
- Axe de pivot espagnol.



## 1735

- Piletta per cerniera. Quadro tedesco.
- Punto de giro inferior para bisagra con cuadro Aleman.
- Bottom pin for hinges with German pivot housing.
- Unterer Zapfen für Band. Deutscher Gehäuse.
- Axe de pivot allemand.



## 1027

- Piletta a soffitto per 1020-1820.
- Punto de giro superior para art.1020-1820.
- Top pin for 1020-1820.
- Deckezapfen für 1020-1820.
- Broche supérieure pour 1020-1820.

